

CLEVERTOUCH

Wireless presentation system included with
Clevertouch S-Series 84"

Wireless Presentation System

Present wirelessly without the need for any cables connected to your PC, notebook or tablet.

Install a driver so you can present interactively - wirelessly, connecting USB to the device.

WiFi doc app to push Excel, PDF's and jpegs to the display. Download the app from the app store, it will ask to access your photos, making sure you are connected to the correct network. You can press "Play" and it will push that photo to the display. If you want to push a file type you will need to choose a file on your device then "open with Wifi doc" this will put the file in the apps library.

Sidepad reviver app, control your PC from a tablet.

4-1 projection, have a quad screen with 4 devices displayed at once.

Conference control, be in control of the meeting by allowing access to users (up to 64 connected at one time). This will ensure that the presenter is in control of the meeting.

Video mode for audio visual synchronisation.

Connect via LAN or as part of your Network.

Find out more at clevertouch.co.uk or call 020 8319 7777.

